
## KAFFELOGIC BOOST MANUAL

## **ACTIVATION**

- Open Kaffelogic Studio.
- 2. Click on the **Help** dropdown menu.
- Click on Activate features.
- Plug the roaster to your computer and power it on using the included USB cable. Or, plug the USB memory stick into your computer.
- Enter your roasters serial number and activation code in the labelled fields.
- 6. Click Activate.

## **INTERFACE**



Press ▶ to load K-logic classic




Select and load your profile. Press ▶ as if you were starting your roast.

Select load size [120q] then >

2



You will be prompted to select a batch size to roast. Use the — and + buttons to increase or decrease your batch size.



3

Using a scale weigh out your coffee to the same weight as your batch size selected into the provided beaker.



Dose your weighed out coffee from the beaker into your roaster. If you are roasting larger batches, attach the BOOST ring. 0:01 L3.5 \* 28.9 K-logic classic



Press ▶ to begin the roast.

## **FURTHER INFORMATION**

- The included BOOST ring is a chamber extension that will stop some beans falling out at higher batches. You can roast smaller batches without it.
- If you want to roast a standard, or "non-boost" roast, select the 120g batch size and roast as normal.
- You can return to the profile screen and by pressing the **L** button.
- When roasting larger batches remove the chaff collector over a bean tray/ bowl to catch any beans that fall above the BOOST ring.

